


# Zwipe Access - Quick Start Guide

#### Card Overview

- 1) Remove Battery Door
- 2) Insert CR2032 Coin Cell Battery (+ side up)
- 3) Close Battery Door

The Card will boot up, and you will see Green & Red LED blinking 3\*0,5 Seconds

This means the card is ready for Fingerprint Enrollment, card registration and application/sector programming.



Fingerprint template is stored in a secure & permanent non-volatile memory; removing the battery will not delete the stored templates.

## System Registration and/or adding Applications (13.56MHz)

Before a fingerprint is enrolled, the Zwipe Access card is unlocked and works like a regular contactless credential allowing the Card Serial Number (CSN) or Facility Code & Badge number to be freely read. Additionally, this is best time to add additional organizational specific applications/sectors to the card (13.56MHz cards only).

Step 1) Turn on card either by entering it into an 13,56 MHz read/write unit or by touching Capacitive "On button"

Touching the fingerprint sensor during registration process initiates enrollment phase. Simply remove card from reader, let the card cycle off and start again.

Step 2) Registration: The reader will read the CSN or FC/Badge # and automatically enter it into your PAC system, or it will display that information for you to enter it into your PAC system. – card is active for 20 sec.

<u>Application programming:</u> Follow standard card programming process and tools (use your existing software and read/write unit). The card is active and programmable for 20 sec.

Step 3) After the card is registered in your PAC system, and/or programmed, proceed to the fingerprint enrollment phase by following the Enrollment Steps in this Guide.



www.zwipe.com

ZAC20160722

## Zwipe Access - Quick Start Guide

### Fingerprint Enrollment

- A High Quality Enrollment of Fingerprint = Better User Experience with Card
- Tips: Wash your hands (to improve fingerprint capture quality)
  - Put finger flat on the sensor, be careful not to use the fingertip
- Turn the card on by touching the capacitive on button,
  The Green & Red LED will blink together 3 times for 0,5 seconds,
  followed by a Green blinking LED indicating card is ready for enrollment.

Put your thumb on the fingerprint scanner:

- Green flashing followed by 1 Sec. solid Green LED = Good Capture
- Green flashing followed by 1 Sec. solid RED LED = Bad Capture, try again
- Once the Green or Red LED times out, remove your finger from the scanner, until you again see a green blinking light.
- 3) Repeat step 1) 2) until you have to 10 good captures
  - Position finger slightly different on each try & try to center finger on fingerprint scanner for better results in enrollment














Watch our Fingerprint Enrollment Video:



#### **Interrupted During Enrollment?**

If you are interrupted during enrollment or want to start over before enrollment was completed, simply allow the card to cycle off and restart the process – No fingerprint templates are stored before enrollment is successfully completed.

4) Once you have 10 good captures, the Green LED will light for 5 seconds to indicate the enrollment was successful, and after this the card will turn off — On next card start, the card is enrolled & ready to use.

Congratulations with your new Zwipe Access card



www.zwipe.com

ZAC20160722